



Council for Development and Reconstruction (CDR)

Ministry of Energy and Water (MoEW)

Water Establishment Beirut and Mount Lebanon (WEBML)

Federal Institute for Geosciences and Natural Resources (BGR), Hannover, Germany

German-Lebanese Technical Cooperation Project


## Public Awareness Campaign for Schools Groundwater Vulnerability

BGR September 2012

Dr. Armin Margane, BGR








#### **Groundwater System**

#### New geological map prepared by BGR







### What is karst and how Groundwater is recharged


The high plateau (1800-3000 m) Is most important for groundwater recharge and thus for drinking water supply. There are more than 2,000 dolines in the high plateau where the melting snow can easily infiltrate.


C4 limestone near Wardeh (upper aquifer)

no major surface water runoffrapid infiltration into Cretaceous aquifer

dolines

- high GW recharge from snow melt






#### **Karst Features**






Sinkhole









#### **How does Groundwater move?**

Groundwater infiltrates into the underground (recharge)

- direct recharge (at the place where it rains) or
- indirect recharge (along the surface water flow path) e.g. in the river bed or depressions
- Mount Lebanon: mainly karstified limestone (dissolution by carbonic acid) groundwater moves along fractures, faults, dissolution channels (conduits)
  - high flow velocities (100-200 m/h; up to 2000 m/h in large conduits!)
  - high water level fluctuations (dry/wet season)

How to determine groundwater flow directions/velocities, groundwater contribution zone?

- tracer tests
- geochemical data
- isotope data (oxygen 18, deuterium, tritium)






#### **Contamination Risks from Wastewater**























#### **Groundwater Flow**

#### **Mean travel times**







#### **Groundwater Protection Measures**

What needs to be done to protect the groundwater resources?

- An inventory of groundwater hazards helps to identify the pollution sources
- A risk assessment for critical pollution sources must be done
- The raw water quality must be controlled to find out whether there is an impact from the pollution source
- A clean-up operation (land reclamation) must be undertaken, if technically and financially feasible
- Contaminants from pollution sources must be collected and treated (wastewater, waste)
- Groundwater protection zones must be established and the related landuse restrictions be implemented and enforced. In protection zones certain landuses and practices are not allowed (new landuse licensing requests)





# Thank you for your kind attention

www.bgr.bund.de/jeita

Dr. Armin Margane – Project Team Leader Raifoun, Saint Roche Street armin.margane@bgr.de +961 70 398027



